

# **PBR Support for Multiple Tracking Options**

#### Last Updated: July 20, 2011

The PBR Support for Multiple Tracking Options feature extends the capabilities of object tracking using Cisco Discovery Protocol (CDP) to allow the policy-based routing (PBR) process to verify object availability by using additional methods. The verification method can be an Internet Control Message Protocol (ICMP) ping, a User Datagram Protocol (UDP) ping, or an HTTP GET request.

- Finding Feature Information, page 1
- Information About PBR Support for Multiple Tracking Options, page 1
- How to Configure PBR Support for Multiple Tracking Options, page 2
- Configuration Examples for PBR Support for Multiple Tracking Options, page 9
- Additional References, page 11
- Command Reference, page 12
- Feature Information for PBR Support for Multiple Tracking Options, page 13

## Finding Feature Information

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the Feature Information Table at the end of this document.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <a href="https://www.cisco.com/go/cfn">www.cisco.com/go/cfn</a>. An account on Cisco.com is not required.

# Information About PBR Support for Multiple Tracking Options

- Object Tracking, page 2
- PBR Support for Multiple Tracking Options Feature Design, page 2

## **Object Tracking**

Object tracking is an independent process that monitors objects such as the following:

- State of the line protocol of an interface
- Existence of an entry in the routing table
- Results of a Service Assurance Agent (SAA) operation, such as a ping

Clients such as Hot Standby Router Protocol (HSRP), Virtual Router Redundancy Protocol (VRRP), Gateway Load Balancing Protocol (GLBP), and (with this feature) PBR can register their interest in specific, tracked objects and then take action when the state of the objects changes.

## **PBR Support for Multiple Tracking Options Feature Design**

The PBR Support for Multiple Tracking Options feature gives PBR access to all the objects that are available through the tracking process. The tracking process provides the ability to track individual objects--such as ICMP ping reachability, routing adjacency, an application running on a remote device, a route in the Routing Information Base (RIB)--or to track the state of an interface line protocol.

Object tracking functions in the following manner. PBR will inform the tracking process that a certain object should be tracked. The tracking process will in turn notify PBR when the state of that object changes.

# **How to Configure PBR Support for Multiple Tracking Options**

The tasks in this section are divided according to the Cisco IOS release that you are running because Cisco IOS Release 12.3(14)T introduced new syntax for IP Service Level Agreements (SLAs). To use this feature, you must be running Cisco IOS Release 12.3(4)T, 12.2(25)S, or a later release. This section contains the following tasks:

- Cisco IOS Release 12.3(11)T 12.2(25)S and Earlier, page 2
- Cisco IOS Release 12.3(14)T 12.2(33)SXH and Later, page 6

## Cisco IOS Release 12.3(11)T 12.2(25)S and Earlier

Perform this task to configure PBR support for multiple tracking options. In this task, a route map is created and configured to verify the reachability of the tracked object.

This task requires the networking device to be running Cisco IOS Release 12.3(11)T, 12.2(25)S, or prior releases.

#### **SUMMARY STEPS**

- 1. enable
- 2. configure terminal
- 3. rtr operation-number
- **4. type echo protocol** *protocol-type target* [**source-ipaddr** *ip-address*]
- 5. exit
- **6. rtr schedule** *operation-number* [**life** {**forever** | *seconds*}] [**start-time** {*hh* : *mm*[: *ss*] [*month day* | *day month*] | **pending** | **now** | **after** *hh* : *mm* : *ss*}] [**ageout** *seconds*]
- 7. track *object-number* rtr *entry-number* [reachability]
- **8.** delay {up seconds [down seconds] | [up seconds] down seconds}
- 9. exit
- **10. interface** *type number*
- **11. ip address** *ip-address mask* [**secondary**]
- **12.ip policy route-map** *map-tag*
- **13**. exit
- **14. route-map** *map-tag* [**permit** | **deny**] [*sequence-number*]
- **15. set ip next-hop verify-availability** [next-hop-address sequence track object]
- 16. end

#### **DETAILED STEPS**

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
		Enter your password if prompted.
	Example:	
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	
Step 3	rtr operation-number	Enters SAA RTR configuration mode and configures an
		SAA operation.
	Example:	
	Router(config)# rtr 1	

	Command or Action	Purpose
Step 4	type echo protocol protocol-type target [source-ipaddr ipaddress]	Configures an SAA end-to-end echo response time probe operation.
	Example:	
	Router(config-rtr)# type echo protocol ipicmpecho 10.1.1.10	
Step 5	exit	Exits SAA RTR configuration mode and returns the router to global configuration mode.
	Example:	
	Router(config-rtr)# exit	
Step 6	rtr schedule operation-number [life {forever   seconds}] [start-time {hh : mm[: ss] [month day   day month]   pending   now   after hh : mm : ss}] [ageout seconds]	Configures the time parameters for the SAA operation.
	Example:	
	Router(config)# rtr schedule 1 life forever start-time now	
Step 7	track object-number rtr entry-number [reachability]	Tracks the reachability of a Response Time Reporter (RTR) object and enters tracking configuration mode.
	Example:	
	Router(config)# track 123 rtr 1 reachability	
Step 8	delay {up seconds [down seconds]   [up seconds] down seconds}	(Optional) Specifies a period of time (in seconds) to delay communicating state changes of a tracked object.
	Example:	
	Router(config-track)# delay up 60 down 30	
Step 9	exit	Exits tracking configuration mode and returns the router to global configuration mode.
	Example:	
	Router(config-track)# exit	

(	Command or Action	Purpose
Step 10 i	interface type number	Specifies an interface type and number and enters interface configuration mode.
E	Example:	
F	Router(config)# interface ethernet 0	
Step 11 i	ip address ip-address mask [secondary]	Specifies a primary or secondary IP address for an interface.
	Example: Router(config-if)# ip address 10.1.1.11 255.0.0.0	See the "Configuring IPv4 Addresses" chapter of the Cisco IOS IP Addressing Services Configuration Guide for information on configuring IPv4 addresses.
Step 12 i	ip policy route-map map-tag	Enables policy routing and identifies a route map to be used for policy routing.
E	Example:	
F	Router(config-if)# ip policy route-map alpha	
Step 13	exit	Exits interface configuration mode and returns the router to global configuration mode.
E	Example:	
F	Router(config-if)# exit	
Step 14 r	route-map map-tag [permit   deny] [sequence-number]	Specifies a route map and enters route-map configuration mode.
E	Example:	
F	Router(config)# route-map alpha	
-	set ip next-hop verify-availability [next-hop-address sequence track object]	Configures the route map to verify the reachability of the tracked object.
E	Example:	
	Router(config-route-map)# set ip next-hop verify-availability 10.1.1.1 10 track 123	
Step 16	end	Exits route-map configuration mode and returns the router to privileged EXEC mode.
E	Example:	
F	Router(config-route-map)# end	

## Cisco IOS Release 12.3(14)T 12.2(33)SXH and Later

Perform this task to configure PBR support for multiple tracking options. In this task, a route map is created and configured to verify the reachability of the tracked object.

This task requires the networking device to be running Cisco IOS Release 12.3(14)T, 12.2(33)SXH, or a later release.

#### **SUMMARY STEPS**

- 1. enable
- 2. configure terminal
- 3. ip sla monitor operation-number
- **4. type echo protocol ipIcmpEcho** { destination-ip-address| destination-hostname } [**source-ipaddr** { ip-address| hostname } | **source-interface** interface-name]
- 5. exit
- **6.** ip sla monitor schedule operation-number [life {forever | seconds}] [start-time {hh : mm[: ss] [month day | day month] | pending | now | after hh : mm : ss}] [ageout seconds] [recurring]
- 7. track object-number rtr entry-number [reachability| state]
- **8.** delay {up seconds [down seconds] | [up seconds] down seconds}
- 9. exit
- **10. interface** *type number*
- **11. ip address** *ip-address mask* [**secondary**]
- **12. ip policy route-map** *map-tag*
- **13**. exit
- **14. route-map** *map-tag* [**permit** | **deny**] [*sequence-number*]
- **15. set ip next-hop verify-availability** [next-hop-address sequence track object]
- 16. end
- 17. show track object-number
- **18. show route-map** [map-name| all| dynamic]

#### **DETAILED STEPS**

	Command or Action	Purpose
Step 1	enable	Enables privileged EXEC mode.
		Enter your password if prompted.
	Example:	
	Router> enable	
Step 2	configure terminal	Enters global configuration mode.
	Example:	
	Router# configure terminal	

Command or Action	Purpose
ip sla monitor operation-number	Starts a Cisco IOS IP Service Level Agreement (SLA) operation configuration and enters IP SLA monitor configuration mode.
Example:	
Router(config)# ip sla monitor 1	
type echo protocol ipIcmpEcho {destination-ip-address  destination-hostname}[source-ipaddr {ip-address  hostname}   source-interface interface-name]	Configures an IP SLA Internet Control Message Protocol (ICMP) echo probe operation.
Example:	
Router(config-sla-monitor)# type echo protocol ipIcmpEcho 10.1.1.1	
exit	Exits IP SLA monitor configuration mode and returns the router to global configuration mode.
Example:	
Router(config-sla-monitor)# exit	
ip sla monitor schedule operation-number [life {forever   seconds}] [start-time {hh : mm[: ss] [month day   day month]   pending   now   after hh : mm : ss}] [ageout seconds] [recurring]	Configures the scheduling parameters for a single Cisco IOS IP SLA operation.  • In this example, the time parameters for the IP SLA operation are configured.
Example:	
Router(config)# ip sla monitor schedule 1 life forever start-time now	
track object-number rtr entry-number [reachability  state]	Tracks the reachability of a Response Time Reporter (RTR) object and enters tracking configuration mode.
Example:	
Router(config)# track 123 rtr 1 reachability	
delay {up seconds [down seconds]   [up seconds] down seconds}	(Optional) Specifies a period of time, in seconds, to delay communicating state changes of a tracked object.
Example:	
Router(config-track)# delay up 60 down 30	
	Example:  Router(config)# ip sla monitor 1  type echo protocol ipIcmpEcho {destination-ip- address  destination-hostname} [source-ipaddr {ip- address  hostname}   source-interface interface-name]  Example:  Router(config-sla-monitor)# type echo protocol ipIcmpEcho 10.1.1.1  exit  Example:  Router(config-sla-monitor)# exit  ip sla monitor schedule operation-number [life {forever   seconds}] [start-time {hh : mm: ss}] [month day   day month]   pending   now   after hh : mm : ss}]  [ageout seconds] [recurring]  Example:  Router(config)# ip sla monitor schedule 1 life forever start-time now  track object-number rtr entry-number [reachability  state]  Example:  Router(config)# track 123 rtr 1 reachability  delay {up seconds [down seconds]   [up seconds] down seconds}  Example:

	Command or Action	Purpose
Step 9	exit	Exits tracking configuration mode and returns the router to global configuration mode.
	Example:	
	Router(config-track)# exit	
Step 10	interface type number	Specifies an interface type and number and enters interface configuration mode.
	Example:	
	Router(config)# interface serial 2/0	
Step 11	ip address ip-address mask [secondary]	Specifies a primary or secondary IP address for an interface.
	Example:  Router(config-if)# ip address 192.168.1.1 255.255.255.0	<ul> <li>See the "Configuring IPv4 Addresses" chapter of the <i>Cisco IOS IP Addressing Services Configuration Guide</i> for information on configuring IPv4 addresses.</li> <li>In this example, the IP address of the incoming interface is specified. This is the interface on which policy routing is to be enabled.</li> </ul>
Step 12	ip policy route-map map-tag	Enables policy routing and identifies a route map to be used for policy routing.
	Example:	
	Router(config-if)# ip policy route-map alpha	
Step 13	exit	Exits interface configuration mode and returns the router to global configuration mode.
	Example:	
	Router(config-if)# exit	
Step 14	route-map map-tag [permit   deny] [sequence-number]	Specifies a route map and enters route-map configuration mode.
	Example:	
	Router(config)# route-map alpha	
Step 15	set ip next-hop verify-availability [next-hop-address sequence track object]	Configures the route map to verify the reachability of the tracked object.
	Example:	• In this example, the policy is configured to forward packets received on serial interface 2/0 to 10.1.1.1 if that device is reachable.
	Router(config-route-map)# set ip next-hop verify-availability 10.1.1.1 10 track 123	as the is reachable.

	Command or Action	Purpose
Step 16	end	Exits route-map configuration mode and returns the router to privileged EXEC mode.
	Example:	
	Router(config-route-map)# end	
Step 17	show track object-number	(Optional) Displays tracking information.
	Example:	Use this command to verify the configuration. See the display output in the "Examples" section of this task.
	Router# show track 123	
Step 18	show route-map [map-name  all  dynamic]	(Optional) Displays route map information.
	Example:	• In this example, information about the route map named alpha is displayed. See the display output in the "Examples" section of this task.
	Router# show route-map alpha	

#### **Examples**

The following output from the **show track** command shows that the tracked object 123 is reachable.

```
Router# show track 123
Track 123
Response Time Reporter 1 reachability
Reachability is Up
2 changes, last change 00:00:33
Delay up 60 secs, down 30 secs
Latest operation return code: OK
Latest RTT (millisecs) 20
Tracked by:
POLITE MD 0
```

The following output from the **show route-map** command shows information about the route map named alpha that was configured in the task.

```
Router# show route-map alpha
route-map alpha, permit, sequence 10
Match clauses:
Set clauses:
ip next-hop verify-availability 10.1.1.1 10 track 123 [up]
Policy routing matches: 0 packets, 0 bytes
```

# Configuration Examples for PBR Support for Multiple Tracking Options

- Cisco IOS Release 12.3(11)T 12.2(25)S and Earlier, page 10
- Cisco IOS Release 12.3(14)T 12.2(33)SXH and Later, page 10

## Cisco IOS Release 12.3(11)T 12.2(25)S and Earlier

In the following example, object tracking is configured for PBR on routers that are running Cisco IOS Release 12.3(11)T, 12.2(25)S, or earlier releases.

The configured policy is that packets received on Ethernet interface 0, should be forwarded to 10.1.1.1 only if that device is reachable (responding to pings). If 10.1.1.1 is not up, then the packets should be forwarded to 10.2.2.2. If 10.2.2.2 is also not reachable, then the policy routing fails and the packets are routed according to the routing table.

Two Response Time Reporters (RTRs) are configured to ping the remote devices. The RTRs are then tracked. Policy routing will monitor the state of the tracked RTRs and make forwarding decisions based on their state.

```
! Define and start the RTRs.
rtr 1
type echo protocol ipicmpecho 10.1.1.1
rtr schedule 1 start-time now life forever
type echo protocol ipicmpecho 10.2.2.2
rtr schedule 2 start-time now life forever
! Track the RTRs.
track 123 rtr 1 reachability
track 124 rtr 2 reachability
! Enable policy routing on the incoming interface.
interface ethernet 0
 ip address 10.4.4.4 255.255.255.0
ip policy route-map beta
! 10.1.1.1 is via this interface.
interface ethernet 1
 ip address 10.1.1.254 255.255.255.0
! 10.2.2.2 is via this interface.
interface ethernet 2
 ip address 10.2.2.254 255.255.255.0
! Define a route map to set the next-hop depending on the state of the tracked RTRs.
route-map beta
 set ip next-hop verify-availability 10.1.1.1 10 track 123
 set ip next-hop verify-availability 10.2.2.2 20 track 124
```

## Cisco IOS Release 12.3(14)T 12.2(33)SXH and Later

In the following example, object tracking is configured for PBR on routers running Cisco IOS Release 12.3(14)T, 12.2(33)SXH, and later releases.

The configured policy is that packets received on Ethernet interface 0, should be forwarded to 10.1.1.1 only if that device is reachable (responding to pings). If 10.1.1.1 is not up, then the packets should be forwarded to 10.2.2.2. If 10.2.2.2 is also not reachable, then the policy routing fails and the packets are routed according to the routing table.

Two RTRs are configured to ping the remote devices. The RTRs are then tracked. Policy routing will monitor the state of the tracked RTRs and make forwarding decisions based on their state.

```
! Define and start the RTRs.
ip sla monitor 1
type echo protocol ipicmpecho 10.1.1.1
ip sla monitor schedule 1 start-time now life forever
```

```
ip sla monitor 2
type echo protocol ipicmpecho 10.2.2.2
ip sla monitor schedule 2 start-time now life forever
! Track the RTRs.
track 123 rtr 1 reachability
track 124 rtr 2 reachability
! Enable policy routing on the incoming interface.
interface ethernet 0
 ip address 10.4.4.4 255.255.255.0
 ip policy route-map beta
! 10.1.1.1 is via this interface.
interface ethernet 1
ip address 10.1.1.254 255.255.255.0
! 10.2.2.2 is via this interface.
interface ethernet 2
ip address 10.2.2.254 255.255.255.0
! Define a route map to set the next-hop depending on the state of the tracked RTRs.
route-map beta
 set ip next-hop verify-availability 10.1.1.1 10 track 123
 set ip next-hop verify-availability 10.2.2.2 20 track 124
```

## **Additional References**

The following sections provide references related to the PBR Support for Multiple Tracking Options feature.

#### **Related Documents**

Related Topic	Document Title
Object tracking within Cisco IOS software	Configuring Enhanced Object Tracking" chapter of the Cisco IOS IP Application Services Configuration Guide
Configuring IP addresses	"Configuring IPv4 Addresses" chapter of the Cisco IOS IP Addressing Services Configuration Guide

#### **Standards**

Standard	Title
No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature.	

#### **MIBs**

MIB	MIBs Link
No new or modified MIBs are supported by this feature, and support for existing MIBs has not been modified by this feature.	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL:
	http://www.cisco.com/go/mibs

#### **RFCs**

RFC	Title
No new or modified RFCs are supported by this	
feature, and support for existing RFCs has not been modified by this feature.	

#### **Technical Assistance**

Description	Link
The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.	http://www.cisco.com/techsupport
To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds.	
Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.	

# **Command Reference**

The following commands are introduced or modified in the feature or features documented in this module. For information about these commands, see the *Cisco IOS IP Routing: Protocol-Independent Command Reference*. For information about all Cisco IOS commands, use the Command Lookup Tool at <a href="http://tools.cisco.com/Support/CLILookup">http://tools.cisco.com/Support/CLILookup</a> or the *Cisco IOS Master Command List, All Releases*, at <a href="http://www.cisco.com/en/US/docs/ios/mcl/allreleasemcl/all\_book.html">http://www.cisco.com/en/US/docs/ios/mcl/allreleasemcl/all\_book.html</a>.

· set ip next-hop verify-availability

# Feature Information for PBR Support for Multiple Tracking Options

The following table provides release information about the feature or features described in this module. This table lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to <a href="https://www.cisco.com/go/cfn">www.cisco.com/go/cfn</a>. An account on Cisco.com is not required.

Table 1 Feature Information for PBR Support for Multiple Tracking Options

Feature Name	Releases	Feature Information
PBR Support for Multiple Tracking Options	12.3(4)T 12.2(25)S 12.2(33)SXH	The PBR Support for Multiple Tracking Options feature extends the capabilities of object tracking using Cisco Discovery Protocol (CDP) to allow the policy-based routing (PBR) process to verify object availability by using additional methods. The verification method can be an Internet Control Message Protocol (ICMP) ping, a User Datagram Protocol (UDP) ping, or an HTTP GET request.
		Due to syntax changes for IP SLAs, a new task and configuration example were introduced in the Cisco IOS Release 12.2(33)SXH.
		The following commands were introduced or modified by this feature: set ip next-hop verifyavailability.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at <a href="https://www.cisco.com/go/trademarks">www.cisco.com/go/trademarks</a>. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams,

and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.